

Best Video Guestbook Phone Ever.

8908S-SMART VIDEO
AUDIO GUESTBOOK

USER MANUAL



Features Overview

- Video recording, audio recording and selfies
- Camera: 13MP; Display Resolution: 800 × 1280 px. Display Size: 8-inches
- 9 languages supported: English, French, German, Italian, Spanish, Arabic, Portuguese (Brazil), Portuguese (Portugal), Chinese
- Adjustable camera angle
- support SIM card and SD card (included 64GB)
- support video calls and messaging
- support the image setting of homepage background
- support Wi-Fi/Bluetooth connection, application management, and system settings
- support bluetooth connnection to printers, allowing instant printing of captured photos.
- Advertisements playback (video and image)
- Maximum audio recording time: 3800 hours
- Maximum video recording time: 32 hours

1.Wedding Mode (Default Mode)

- The device boots into Wedding Mode by default.
- Tap [Switch Mode] and enter management password 8908 to switch to Host Mode.

1.1 Leave Audio

- Operation Steps:
 1. Lift the handset or tap the screen to enter the main interface.
 2. Tap [Leave Audio] .
 3. Start recording automatically after three seconds.

1.2 Leave Video-Take off the handset

- Operation Steps:
 - 1.Lift the handset and automatically enter the video message interface.
 - 2.Tap the screen to enter the main interface [Leave Video] .
 - 3.Start recording automatically after three seconds.
 4. Tap [] to end recording.
 5. Select [] / [] / [] .
- The system saves and exits automatically after 30 seconds of inactivity (settable).
- Note: One hour of video recording requires approx. 4.08 GB.

1.3 Take Photos

- Operation Steps:
 - 1.Tap the screen to enter the main interface.
 - 2.Tap [Take Photo] .
 - 3.3s countdown afer you press the camera icon

4. After capturing, select [] / [] / []

- If inactive for 30 seconds (settable), the system saves and exits automatically.

2. Host Management

- Enter Home Mode by tapping [Switch Mode] in Wedding Mode and entering password 8908.
- Leave Audio, Leave Video, and Take Photo operate the same as in Wedding Mode.

2.1 Host Greeting (Video)

Recording:

- 1.Tap [Host Greetings].
- 2.Tap [Record].
- 3.Start recording automatically after three seconds.
4. Tap [] .
5. Select [] / [] / [] .

- System auto-saves after 30 seconds (settable) of inactivity.
- In the Gallery, you can set recorded videos or videos transferred from external devices as greeting messages. In Wedding Mode, when a guest lifts the handset, the Guestbook will automatically play the greeting video.

2.2 View Captured Media

- Audios: Play, Delete
- Videos: Play, Delete
- Photos: View, Zoom, Delete, Print. Set the screen background.
- Photos can support printing, just connect to the printer via Bluetooth or Wi-Fi.

2.3 Advertisement Settings (Photo/Video)

- Supports viewing, playing, setting as home-screen advertisement and homepage background (Wedding mode) , and deleting video and image ads.
- Note: Ad files must be copied from a computer before they can be displayed.

2.4 Settings--General

- Supports Settings for Audio Recording Duration, Video Recording Duration, Passwords, Emergency SOS number (not support), and Background Image etc.
- From the main interface, go to [Settings] → [General] → [System Settings]:
 1. [Network & Internet]: Internet Connection, Airplane mode. Hotspot & tethering.
 2. [Connected Devices]: Bluetooth pairing/connection, Connection preference.
 3. [App Management]: Installed apps, recent apps, default apps, permissions.
 4. [Notifications]: App notifications, history, Conversations, Do Not Disturb, alerts, status bar settings, Blink Light.
 5. [Battery]: Percentage display, optimization, power saving, Battery percentage etc.
 6. [Storage]: Device storage, SD card storage, file management.
 7. [Sound]: Media volume, call volume, Ring & notification volume, alarm system, touch sounds, charging tone, DND settings (Do Not Disturb) etc.
 8. [Display]: Brightness, Lock display, appearance, color etc.

9. [Scheduled Power On/Off]: Auto on/off times.

10. [Accessibility]: Magnification, dark theme, interaction controls, assistive features.

11. [Security]: Screen lock, SIM lock, device management, encryption.

12. [Privacy]: View and manage privacy-related settings.

13. [Safety & Emergency]: Emergency info, wireless alerts.

14. [Passwords & Accounts]: Autofill, account management, sync settings.

15. [System]: Language & input, date & time, gestures & navigation, multi-user management, reset options.

16. [About Device]: Device name & model, SIM status, system version, IMEI, IP & MAC address, device info.

2.5 Phone & Messaging Functions

1. Phone:

- Make/receive calls
- Contacts management: add, edit, delete, search, share
- Receive/send SMS

2. SMS/MMS:

- View/receive/sent messages
- Edit and send new messages
- Group messaging supported
- View conversation history, archived chats
- SIM card message management
- Wireless emergency alert info.

3. Installation & Power

1. SIM and SD card:

- Insert SIM/SD according to markings when powered off.

2. Power connection:

- There is a Type-C port on the back of the device. Use a data cable to connect it to a stable power source.

3. Power on:

- When the battery icon appears after connecting to the power, press the Power key to turn on.

4. File Access & Transfer

After connecting to a computer:
Navigate to 8908S — SD Card — 8908S

- Ads — advertisement files
- Host greeting — host greetings
- Captured media — captured media except host greetings